# PMID702C, PMID703C, PTAB7XC: User Manual

**11/01/2012**

Polaroid

7" Internet Tablet

Camera + Capacitive Touch Screen

PMID702C / PMID703C / PTAB7XC

User Manual

## In the box

Tablet

User Manual

USB Cable

AC Adapter

## Location of controls

Front Camera

Home Button

Speaker

Reset

Headphone Jack

USB Port

Power On/Off/Lock

MicroSD Card Slot

Volume

**Specifications:**

Operating System : Android 4.0, Ice Cream Sandwich
Processor: ARM CORTEX-A8
Processor Speed : 1 GHz
RAM : 512MB SDRAM
Graphic accelerator : OpenGL ES 2.0 (3D game support)

Display :
- Capacitive multi-touch screen
- Display resolution : 800*480 (16:9)
- 4 way auto rotation

Network : WiFi (802.11 b/g/n)

Memory :
- Internal Memory : 4GB
- External Memory : Micro SDHC card slot (max 32GB)

## Basic operation

**Charging the battery:**
Connect the tablet to a wall outlet using the included AC adapter.

Wall outlet | AC adapter | USB plug (see illustration)

The tablet may also be charged by connecting it to a computer using the USB cable, however, it will take much longer to fully charge.

**Approximate play times**
(actual play times may vary depending on display and power settings)
- Music: up to 10 hours (Wi-Fi / backlight off)
- Video: 4.5 - 5 hours (Wi-Fi turned off)
- eBook: 6 - 7 hours (Wi-Fi turned off)
- Web browsing : 5 - 6 hours
- Standby time: 60 - 70 hours

**Battery Tips:**
- *To turn off Wi-Fi when it's not in use.*
- *Lock the tablet the display is off to shorten charging time.*
- *To optimize battery time and performance, adjust the "Brightness" and "Screen timeout" options in the Settings app.*

**Turning on the tablet**

Startup screen

Press and hold the ⏻ button until the startup screen appears.

**Unlock (enter) the tablet**

Slide the "Lock icon" to the right.

Lock icon

Lock screen

**Look (standby) the tablet**
To lock or unlock the tablet, briefly press the ⏻button. Lock the device to conserve the battery.

**Turning off the tablet**
For quick power-off, you can select the "Power" button on the Polaroid Settings widget to turn off the tablet.

Polaroid Settings widget

Power button

Press the Power button, and the Power off dialog appears.

Power off

Would you like to shut down?

Cancel | OK

## Home screen

On the Home screen, you can place app shortcuts and widgets.

**Home screen (left)**
**Polaroid Media widget**

Polaroid Media widget

Google search

**Home screen (center)**
**Polaroid Home widget**

Polaroid Home widget

**Home screen (right)**
**Polaroid Settings widget**

Polaroid Settings widget

Access Apps & widgets screen

Shortcuts

Swipe the screen left or right to access other Home screens

### Access apps & widgets screen

Press ⋮⋮⋮ to access the Apps & Widgets screens.

Apps screen

Press the ⌂ icon to return to the Home screen.

Swipe the Apps & Widgets screen left or right to access more apps and widgets.

**Placing apps & widgets on the Home screen**
Press & hold an app or widget to place it on one of the Home screens.

Widgets screen

Apps screen

Press & Hold

Please an app shortcut on the Home screen

Move & Release

Home screen

**Removing shortcuts or widgets**
Press and hold the app or widget and slide it as shown below.

Remove

You can always bring the widgets back from the Widgets screen.

Widgets screen

## Connecting to Wi-Fi & downloading apps

### Status Bar

The Status Bar is available on all screens and apps of the tablet.

Tap here to expand the menu and view more options

Multi-tasking

Browser

Email

Clock & Notifications
Tap the Clock to display Notifications & Settings shortcuts

Wednesday February 22, 2012 12:00

Home Wi-Fi 100%

USB connected
Select copy files to/from your computer

Menu

Wallpaper

Manage apps

System settings

Previous | Home | Multi tasking | Volume – | Volume + | Menu | USB (if it's connected) | SD card | Clock & Notifications | Wi-Fi | Battery

**Setting up Wi-Fi**
To browse web sites, use e-mail and download apps, you must first connect the tablet to the internet.

To set up Wi-Fi, use the "Polaroid Settings" widget on the Home screen.

Settings | Wi-Fi Setup | Online Help | Power | Download App Stores

Polaroid Settings widget

1. Swipe the Home screen to the left to access the Polaroid Settings widget.

Swipe the screen left

2. Select "Wi-Fi Setup".

Home screen (right)
Polaroid Settings widget

3. Select a network.

Settings | SCAN | ADD NETWORK

Home Wi-Fi
Secured with WPA2

Wi-Fi Network
Secured with WPA2

i-Dispatcher
Secured with WEP

4. If required, enter the correct password and select "Connect".

Home Wi-Fi

Signal strength: Excellent
Security: WEP
Password

Show password

Show advanced options

Cancel | Connect

Select "Show password" to avoid mistakes.

5. When the tablet is connected to a network, the Wi-Fi icon will appear on the Status Bar and "Connected" will appear under the selected network.

12:00

To conserve battery life, turn off Wi-Fi when not connected to a network.

### Downloading an App Store

To access a large library of free/paid apps and games, you need to download an app store. We have selected links to the most popular ones. These links are accessed by selecting the "Download Apps Stores" option on the Settings widget.

1. After successfully connecting the tablet to Wi-Fi, select "Download App Stores" on the Polaroid Settings widget.

Settings | Wi-Fi Setup | Online Help | Power | Download App Stores

Polaroid Settings widget

2. Select an app store, and follow the instructions to download and install it on the tablet.

app store options

3. Click here.

4. Select the downloaded app store (.apk file) from the Pop-up window.

5. Select "Install" to install the app.

Install screen

6. The app store appears on the Apps screen.

Apps screen

### Downloading and installing apps:

After downloading the selected app store, it is possible to download and install apps directly to the tablet - these apps will appear on the Apps screen.

***Note: Apps compatibility / games:***

*There are many apps available on the various app stores, but unfortunately not all will be compatible with the tablet. This is because many of the apps are designed for mobile phones and require functions or specifications that are not supported by the tablet. We recommend always searching for the free or "Lite" version of an app and testing it before purchasing the paid app.*

**Avoid apps that require rear cameras or GPS as these apps will not be supported by the tablet.*

*The tablet supports many game apps - although we recommend always testing the free version (if available) before purchasing.*

***Note: Polaroid and the manufacturer of this tablet are not affiliated with, connected to, or sponsored by Amazon or the Amazon appstore.***

### Games

Sometimes, while playing games, the gsensor on the tablet may be too sensitive, causing the game to be difficult to controllable. To correct this problem, follow the steps below:

1. Open "Settings."
2. Select "Display."
3. Select "Accelerometer Coordinate System."
4. The default setting is, "Default Coordinate System." This setting should work for most games.
5. In case your game is not functioning properly, select "Special coordinate system to support some other games".

Settings | Brightness | Wallpaper | Auto-rotate screen | Sleep | Font size | Accelerometer coordinate system

## Camera and video chat

### Front facing camera

Select 📷 on the apps screen to go to camera mode. It is possible to take pictures or videos with the built-in, front facing camera.

Camera app

Camera

Apps screen

Access pictures & videos

Zoom +

Take picture / video

Settings

Zoom -

Camera mode

Camera | Video

Select the picture to go to the pictures folder of the gallery app where all the pictures and videos are saved.

Return to camera mode

**Share pictures to Email, Facebook or Twitter:**
To utilize this feature you must have a Facebook or Twitter account and be logged in, for Email, an account must be set up for this option to appear.

Sharing pictures

### Video chat

Use the built-in, front facing camera to video chat with friends and family.
There are many different services that offer video chat, which are available on the app stores.

**FRONT**

## Web browsing

Select 🌐 "Browser" on the Home or Apps screen. You must connect to Wi-Fi before accessing the web.

Select for Browser options

Request desktop site

Mobile browser mode

Request desktop site

Desktop (Full view) browser mode

## Setting up e-mail

Select ✉ "Email" on the Home or Apps screen and follow the instructions to set up your email account on the tablet. You must connect to Wi-Fi before accessing or setting up email accounts.

Email account

Email Setup screen

Click to access Email settings

INBOX screen

## Photo gallery

Access pictures and videos stored on the tablet.

**Viewing pictures:**
Pinch to enlarge and swipe to go to previous or next pictures.

**Watching videos:**
While playing a video, tap the display to access the video controller, tap the display again to hide the controller.

**Share pictures to Email, Facebook or Twitter:**
To utilize this feature you must have a Facebook or Twitter account and be logged in, for Email, an account must be set up for this option to appear.

- Share: Share the selected picture through Email, Facebook, or Twitter
- Trash: Delete the selected picture
- Menu: Slideshow, edit and more

## Transferring and managing files

It is possible to manage and transfer media files to the tablet by connecting it to your computer.

**Conserve Internal Memory!**

It is strongly recommended to purchase and install a Micro SD card before transferring or downloading media files.

Micro SD card

***Tips:*** *Transfer and store media files such as music, pictures and video on to a Micro SD card and avoid placing these types of files in the internal memory of the tablet - this will conserve the internal memory, and allow you to download more apps.*

**Inserting Micro SD card**
The tablet supports Micro SD cards up to 32GB (not included).

**To install a Micro SD card into the tablet:**

1. Insert the card face up into the card slot until it clicks and locks into place.

Lock icon

Lock screen

Face up

2. Once the card is mounted, the card icon appears on the Status Bar.

Micro SD card is mounted

USB connected

Select "Turn on USB storage"

3. To access the Micro SD card, select "File Manager" from the Apps screen.

File Manager

**Unmount & remove the Micro SD card:**

1. Open "Settings."
2. Select "Unmount Micro SD card."
3. It is now safe to remove the card from the tablet.
4. To remove the card, gently push it in until it pops out.

Settings

Erase SD card
Delete all data on SD card, such as music and photos

Total space
Used
Available
Unmount SD card
Safely remove SD card

Enable media scanning on

Unmount SD card

***Tip:*** *A card can only be inserted one way - do not use force when inserting the card.*
*Make sure to unmount the card before taking it out of the tablet.*

**Connecting the tablet to a PC or Mac:**

1. Connect the included USB cable to the "USB port" of the tablet and USB port of the computer.

USB port

Connect the USB cable to the USB port on PC

PC

Minimum system requirements:
- Windows 2000, XP, Vista, 7
- Mac OS X 10.5 or later
- both USB connected

2. The "USB connected" screen appears, select "Turn on USB storage", then select "OK."

Press to unmount the USB connected screen

USB connected

Select copy files to/from your computer

Unmount | Cancel | Turn on USB storage

Previous to unmount the USB connected screen

USB Connected screen

***Note:*** *While connected to the computer, you can also access the "USB connected" screen from the Status Bar as shown below.*

USB connected | Unmount | Clock | "USB connected" screen

3. The "AutoPlay" window appears on your computer's display select "INTERNAL" to view and manage files on the tablet, or if a Micro SD card is inserted, select "Removable Disk" to manage files on the card.

AutoPlay

Always do this for pictures

Import pictures and videos using Windows

Open folder to view files

Speed up my system using Windows ReadyBoost

View more AutoPlay options in Control Panel

"Removable Disk" window appears if a Micro SD card is inserted

## Browsing files

**File Manager:**
To view, open, copy or delete files on the internal memory of the tablet, inserted Micro SD card or USB stick, select "File Manager" on the Apps screen.

Go back to the previous folder | Go to internal memory | Go to microSD card | Go to USB | Go to pictures | Go to movies | Settings | Folder actions

Briefly press a file or folder to open it.

Press to open
**Press & Hold for Options**

**Copy, move or delete a file or folder:**

1. Press and hold a file or folder until the options window appears, then select an option from the options window.

Option window

2. Select a file or folder.

3. If you select "Copy" or "Move", press and hold on a folder and select "Paste into folder" to copy the file there.

4. Copy media files from your computer to the Micro SD card.

Media files on your computer

Conserve Internal Memory!
Transfer media files to "Removable Disk" (Micro SD card)

***Tips:*** *Organize your media (pictures, videos and music) by creating folders such as "Pictures", "Videos" and "Music" on the Micro SD card as shown below.*

"Removable Disk"
Access the Micro SD card

5. Select "Turn off USB storage" on the tablet to disconnect it from the computer.

## Multimedia

Use the tablet to store and play music, pictures and video files.

**Music**
Access music files stored on the tablet.

Music screen

Press & hold a song title, then select an option from the menu

Music playback screen

Music playback options

## Settings

**Settings app:**
Customize and select options to increase battery performance, WiFi options, manage apps and more.

Settings screen

## Online help

Select "Online Help" on the Apps screen to access:
- App stores
- Firmware updates
- Technical support
- Product registration

Online Help screen

## Resetting

In the event that the tablet freezes or does not function properly, try connecting the problem by pressing the RESET button located on the back panel shown below.

Use a paper clip or the tip of a stylus to press the RESET button. Data stored on the tablet will not be affected by using the RESET button.

Reset

## Restore

***Note:*** *If the problem persists it may be necessary to restore the tablet to the factory default settings.*

*1) Select "Settings" from the Apps screen.*
*2) Select "Reset to factory default settings"*
*3) Select "Factory data reset" (this will erase data stored on the device so make sure to back up your data prior to using this option).*

## Legal information

**FCC Part 15:**
This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Do not attempt to repair or modify this equipment. Warning: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation."

Shielded USB cables must be used with this unit to ensure compliance with the Class B FCC limits.

PLR IP Holdings, LLC, its licensees and affiliates, fully support all electronic waste initiatives. As responsible stewards of the environment, and to avoid violating established laws, you should properly recycle this product. Please contact your local waste regulations, directives or other governances in the area where you reside. Please check with local authorities or the retailer where you purchased this product to determine a location where you can appropriately dispose of the product.

You may also go to HYPERLINK "http://www.polaroid.com" www.polaroid.com and reference About / Electronic Recycling to learn more about the specific laws in your area and to locate a collection facility near your home.

If your electronic device has internal memory on which personal data is stored, please be aware that you may want to perform a data sanitization process before you dispose of your device to assure another party cannot access your personal data. Data sanitization varies by the type of product and its software, and you may want to research the best sanitization process for your particular device. You may also check with your local recycling facility to determine their data sanitization procedures during the recycling process.

## Restore

***Note:*** *If the problem persists it may be necessary to restore the tablet to the factory default settings.*

*1) Select "Settings" from the Apps screen.*
*2) Select "Reset to factory default settings"*
*3) Select "Factory data reset" (this will erase data stored on the device so make sure to back up your data prior to using this option).*

## Limited Warranty

This product as supplied and distributed new by AIT Inc. ("AIT") to the original consumer purchaser is warranted by AIT against manufacturing defects in workmanship for a period of one year from such date of purchase ("Warranty").

In the unlikely event that this product is defective, or does not perform properly, you may within one year from your original date of purchase return it to the authorized service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:

- Provide proof of the date of purchase within the package (Dated bill of sale).
- Prepay all shipping costs to the authorized service center. Insure the package or assume risk of loss.
- Include a return shipping address (no P.O. Boxes), a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping, will require you to file a claim with the carrier.

The shipping address of the authorized service center is:

iNAIT Inc.
Attention: Customer Service (2nd Floor)
144-2 53rd Street
Brooklyn, NY 11232

IN NO EVENT WILL AIT, ITS MANUFACTURERS, DISTRIBUTORS OR PLR IP HOLDINGS, LLC BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) RELATED TO THIS PRODUCT, EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY.

Should you have any questions or problems concerning this product, please contact our customer service department at:

**Customer Support:**
☎ 1-877-358-6481 (Toll Free)
✉ polaroidtabletsupport@southerntelecom.com

Monday - Friday: 8AM - 10PM (EST)

internetablet

Polaroid

**BACK**